



## OFFSET LESS THAN 1-FEET

## NOTES:

- SEE CONSTRUCTION PLANS FOR LIMITS AND DETAILS OF PHASE 1 CONSTRUCTION.
- 2. ENCASE DUCTILE IRON PIPE WITH TWO LAYERS OF 8-MIL POLYETHYLENE WRAP USING ADHESIVE TAPE.
- COAT ALL FITTINGS, VALVES AND BOLTED COUPLINGS WITH NO-OX-ID WAX AND WRAP. THEN ENCASE WITH TWO LAYERS OF POLYETHYLENE WRAP.
- 4. CONNECTION SHALL BE WITH BOLTED COUPLING, BELL JOINT, OR TRANSITION COUPLING.

