



NOTES:

1. BRASS PLUG TO BE IN PLACE AT ALL TIMES WHEN RELIEF ASSEMBLY IS NOT IN USE AND PRIOR TO BACKFILLING TRENCH
2. FOR 4" DI PIPE USE 1" BRONZE SERVICE CLAMP, 1" x 1-1/2" CORPORATION STOP, AND 1-1/2" x 2" BRASS REDUCER.
3. CORPORATION STOP MUST BE REMOVED AND REPLACED WITH PLUG DURING FINAL TIE-IN.

CHLORINATION AND CONSTRUCTION TAP ASSEMBLY

WDS - 108



Long Beach Water
 Exceptional Water • Exceptional Service

RECOMMENDED

Robert Johnson

DIRECTOR OF ENGINEERING

APPROVED

Debra Paul

DEPUTY GENERAL MANAGER / CHIEF ENGINEER

DATE: 02-2020

SCALE: N.T.S.

SHEET 1 OF 1